



Sleep Massager

OWNERS MANUAL AND OPERATING INSTRUCTIONS

Model 1220 Massage System

Relax and Revive with Comfort Ease® in your Bed!

COMFORT EASE® FEATURES

Use on Twin, Full, Queen, or King size mattress*

Use on inner spring, air, foam mattresses or any furniture cushion

Low Voltage, entire system is ETL listed

Six months limited warranty

**2 units recommended with King size mattresses.*

***This product is not recommended for water beds.*

See our complete line of products at www.comfort-ease.com

©2010 Raffel Systems

IMPORTANT SAFETY INSTRUCTIONS

WARNING: To reduce risk of burns, fire, electric shock, or injury to persons:

- **READ INSTRUCTIONS BEFORE USING**
- **BURNS MAY RESULT FROM IMPROPER USE**
- **NEVER REMOVE COVERS**

IMPORTANT: Patients using a pacemaker should consult a physician prior to use.

This appliance should never be left unattended when plugged in. Unplug from outlet when not in use, and before putting on or taking off parts.

Close supervision is necessary when this unit is used by, on, or near children, invalids, or disabled persons.

Use this unit only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer. Keep the cord away from heated surfaces. Do not use outdoors.

Do not operate where aerosol (spray) products are being used or where oxygen is being administered.

Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the appliance to a service center for examination and repair.

INSTALLATION INSTRUCTIONS

For Household Use

1. Connect each motor into the Zone slots in the junction box.
2. Connect 12V Power Supply into junction box where indicated and plug into a wall outlet.
3. Place both motors between foundation and mattress or cushion where massage is desired.



OPERATING INSTRUCTIONS



POWER key

Press once to turn on, press again to turn off. Press and hold to change timer setting. The power LED changes color to indicate timer setting change. Automatic timer settings are 15 minutes (Green), 20 minutes (Amber), and 30 minutes (Red).

ZONE keys

Press Zone keys to select which motor to run for massage .

MODE keys

Select WAVE, PULSE, or STEADY by pressing the correlating button.

SPEED keys

Press - to decrease speed, and press + to increase speed of massage motors. (speed does not work on steady mode)

INTENSITY keys

Press - to decrease, and press + to increase intensity of the massage.

SAVE THESE INSTRUCTIONS

Six Month Limited Warranty

Comfort Ease warrants its products against all defects in materials and workmanship for a period of six months from the date of purchase, subject to the following terms and conditions:

This warranty applies only for normal use of the product, and shall not be effective for products or parts which do not function properly due to misuse, alteration, installation, accident, negligence, misapplication, modification, improper maintenance or commercial use, or if any product or part has been serviced or repaired by other than Comfort Ease. This warranty extends only to consumers and does not extend to Retailers.

This warranty is effective only if the product is operated in the country in which the product was purchased. A product that requires modifications or adoption to enable it to operate in any other country than the country for which it was designed, manufactured, approved and/or authorized, or repair of products damaged by these modifications is not covered under this warranty.

Liability of Comfort Ease, shall be limited to repair or replacement of any defective product or part, which option shall be the sole decision of Comfort Ease. This warranty is effective only on behalf of the original owner of the product and is not transferable. This warranty is effective only if the user manual instructions have been followed.

To obtain warranty service on this product, mail the product and your dated sales receipt (as proof of purchase), postpaid, to the following address:

Comfort Ease® Consumer Relations

AMERICAN ENTERTAINMENT, INC.

7021 Saint Charles Ln NE

Bremerton, Washington 98311

(360)698-9331

sales@magicfingers.com