

# Magic Fingers<sup>TM</sup>

Bed Relaxation System  
Patent Pending

Easy Installation Instructions

Congratulations!

on your purchase of Magic Fingers <sup>TM</sup> Bed  
Relaxation System. Soon you will  
experience the most relaxing sleep ever!  
Please read the entire instruction manual  
before installing Magic Fingers<sup>TM</sup>.

Magic Fingers <sup>TM</sup> - For A Great Night's Sleep

# Welcome...

Your Magic Fingers Bed Relaxation System <sup>TM</sup> consists of:

- \* The digital, hand-held clock timer
- \* Bed massaging motor unit
- \* Two metal brackets with nylon straps
- \* Four nylon fasteners

## INSTALLATION INSTRUCTIONS

Step 1.....Slide nylon strap set attached to the "T" shaped brackets ends between boxspring and mattress





BRACKET (A)



BRACKET (B)

Brackets (A) and (B) should be placed on each side of boxspring with bracket bottoms facing down so that second nylon strap set can attach around the underneath of the boxspring. Hang each at 90° angle draped over each side of boxspring. Pull strap end at buckle until each side is firmly in place as shown below:



Step 2.....Slide motor unit (C) into bracket (B) with **BOTTOM** of unit against boxspring. Note: Be sure to insert so that power and timer cords are located into notched oval bracket cutout.




MOTOR (C)



UNIT (C) INTO (B)

Step 3.....With unit held securely in place with fastened upper nylon straps, attach underneath strap around bottom of box spring, insert into buckle and tighten until entire unit is firmly in place. NOTE: do not overly tighten straps----clasp may disconnect from the buckle. If this occurs, loosen strap, re-fasten and try again.



(CROSS-VIEW)

## ALTERNATIVE SYSTEM INSTALLATION

Our simple-to-use installation method can be used in other types of sleep systems. If no box spring exists such as in futons, foundation beds, hide-a-ways, roll-away beds, etc. simply wrap the straps around the mattress in the same manner as described above and connect underneath. Secure tightly both strap sets.

Run the power cord from the vibrator motor unit and plug into a wall outlet and touch the "ON" button. Unit will begin to vibrate. **CHECK TO MAKE SURE MOTOR UNIT IS SECURELY IN PLACE. INSTALLATION IS NOW COMPLETE.....**

**HAVE A GREAT NIGHT'S SLEEP!!!!!!**

**Our System is great for traveling-----sets up to a bed in minutes without tools.**

## Troubleshooting

1...If unit does not start: Make sure the wall switch has been turned on. If the motor unit does not start once the power cord has been plugged into the wall, make sure you have pressed the top of the clock timer "ON" button firmly. If the LED clock does not flash, then the timer may be defective and should be returned to our factory for replacement.

2...Massaging unit will not turn off after pressing "OFF" button. If the vibrating unit is running but the "OFF" button on the clock timer does not turn the motor unit off when pressed, there may be a defective "OFF" button. Return to our factory for replacement or repair.

For prolonged life of our motor unit system, we suggest a 30 minute waiting period between each use. For extension or replacement cord, use 16 AWG-all neoprene type electrical cord.

## SETTING THE CLOCK TIMER

MODEL #3255

1) Plug power cord into wall outlet---LED should flash "12:00"

2) Set timer switch on side to "REAL TIME", then touch "HRS" and "MIN" to set actual time. Note:"PM" indicator light on LED display.

3) To program the massaging motor to start at a specific time, hold down button marked "ALARM SET MAGIC FINGERS". Touch "HRS" and "MIN" buttons to desired time. Move the side switch to "MAGIC FINGERS". The indicator alarm light (ALM) on the LED will remain on. When activated by alarm setting, the unit will remain on for 2 hours.

4) To activate unit at any time, press "ON" button. The unit will activate for 59 minutes.

5) Touch "OFF" button to stop unit.

6) To operate unit for a desired amount of time (e.g. 25 minutes only), touch and hold down the "ON" and "MIN" buttons to activate 59 minute countdown until desired massage time is obtained, then release both buttons. The unit will remain on for the balance of time shown.

7) Real time is displayed at all times unless "ALARM SET MAGIC FINGERS" button is touched, revealing pre-set activation time.

## Technical Specifications

Power:	120v 60 hz
Motor and timer:	22 watts
Motor size:	8"L x 53/8"W x 3"H
Timer size:	21/4"L x 31/2"W x 1"H

For our customers who prefer placing our massaging motor directly into their box spring for a permanent installation without the two wire brackets, we have included four nylon ties which get threaded into the small slots on the four sides of the motor base. To utilize this method, simply hang the unit upside down with the base (bottom) of the unit below the grid wire or wooden slats and tie around four opposing areas to securely hold the motor tightly in place. Ties should be evenly looped around supports or grid wires. Tighten all ties, and it's complete.

## **Benefits**

Magic Fingers <sup>TM</sup> works gently with your bed system to provide a soothing vibration massage which induces a restful and peaceful feeling. It takes several minutes to fully enjoy its benefits and often a few uses before appreciating its gentle-acting motion on your body. It is NOT intended to actively shake the bed, instead it enables the body to quietly relax itself into a deep and restful state. Placing your head sideways onto the pillow will further enhance its effects through both feel and sound.

**NOTE:** People with medical conditions should first check with their doctor before using this product. If you have any questions about Magic Fingers Bed Relaxation System, please feel free to call us.

- \* Enjoyed by millions for over 40 years
- \* Promotes sound, restful sleep
- \* Helps reduce stress
- \* Soothes muscle aches and pains
- \* Gently massages your entire body
- \* Enhances total relaxation
- \* Pre-set 59 minute massage cycle
- \* Programmable clock timer activates bed
- \* Specially designed "on/off" touch buttons
- \* Installs in minutes without tools
- \* Uses less than 25 watts of power
- \* Great for traveling and recreation

AMERICAN ENTERTAINMENT, INC.  
7021 Saint Charles Ln NE  
Bremerton, Washington 98311  
(360)698-5331  
[sales@magicfingers.com](mailto:sales@magicfingers.com)

**Magic Fingers <sup>TM</sup> - For A Great Night's Sleep**